

THE HALF POWER BANDWIDTH METHOD FOR DAMPING CALCULATION

By Tom Irvine
Email: tomirvine@aol.com

January 29, 2005

Introduction

Damping in mechanical systems may be represented in numerous formats. The most common forms are Q and ξ , where

Q is the amplification or quality factor

ξ is the viscous damping ratio or fraction of critical damping.

These two variables are related by the formula

$$Q = \frac{1}{2\xi} \quad (1)$$

An amplification factor of $Q=10$ is thus equivalent to 5% damping.

The Q value is equal to the peak transfer function magnitude for a single-degree-of-freedom subjected to base excitation at its natural frequency. This simple equivalency does not necessarily apply if the system is a multi-degree-of-freedom system, however.

Another damping parameter is the frequency width Δf between the -3 dB points on the transfer magnitude curve. The conversion formula is

$$Q = \frac{f_n}{\Delta f} \quad (2)$$

where f_n is the natural frequency.

The -3 dB points are also referred to as the “half power points” on the transfer magnitude curve.

Equation (2) is useful for determining the Q values for a multi-degree-of-freedom system as long as the modal frequencies are well separated.

Single-degree-of-freedom System Example

Consider the single-degree-of-freedom system in Figure 1.




Figure 1.

Given:

1. The mass is 1 lbm (0.00259 lbf sec²/in).
2. The spring stiffness is 1000 lbf/in.
3. The damping value is 5%, which is equivalent to Q=10.

The natural frequency equation is

$$f_n = \frac{1}{2\pi} \sqrt{\frac{k}{m}} \quad (3)$$

The resulting natural frequency is 98.9 Hz.

Now consider that the system is subjected to base excitation in the form of a sine sweep test. The resulting transfer function magnitude is given in Figure 2, as calculated using the method in Reference 1.




Figure 2. Single-degree-of-freedom System

The peak transfer function magnitude is equal to the Q value for this case, which is $Q=10$.

Two-degree-of-freedom System Example

Consider the two-degree-of-freedom system in Figure 3.




Figure 3.

(The dashpots are omitted from Figure 3 for brevity).

Given:

1. Each mass is 1 lbm (0.00259 lbf sec²/in).
2. Each spring stiffness is 1000 lbf/in.
3. Each mode has a damping value of 5%, which is equivalent to $Q=10$.

The resulting natural frequencies are 61.1 Hz and 160.0 Hz, as calculated using the method in Reference 2.

Now consider that the two-degree-of-freedom system is subjected to base excitation in the form of a sine sweep test. The resulting transfer function magnitude is given in Figure 4.




Figure 4. Two-degree-of-freedom System

Each mass is represented by a separate curve in the transfer function plot. The Q value for each mode cannot be determined by simple inspection for this case.




Figure 5. Two-degree-of-freedom System, First Mode

The -3 dB points occur at 57.9 Hz and at 64.1 Hz

The Q value for the first mode is calculated as

$$Q = \frac{f_n}{\Delta f} \quad (4)$$

$$Q = \frac{61.1}{6.2} = 9.9 \approx 10 \quad (5)$$




Figure 6. Two-degree-of-freedom System, Second Mode

The -3 dB points occur at 152.3 Hz and at 167.9 Hz

The Q value for the second mode is calculated as

$$Q = \frac{f_n}{\Delta f} \quad (6)$$

$$Q = \frac{160}{15.6} = 10.3 \approx 10 \quad (7)$$

References

1. T. Irvine, The Steady-state Response of Single-degree-of-freedom System to a Harmonic Base Excitation, *Vibrationdata*, 2004.
2. T. Irvine, The Generalized Coordinate Method for Discrete Systems Subjected to Base Excitation, *Vibrationdata*, 2004.